David Yeomans

ISBN 978-0-7277-6438-6

<https://doi.org/10.1680/rhts.64386.151>

ICE Publishing: All rights reserved

Index

- A-frame, 70, 71–72, 77, 138–140
- abutments, 43
- adhesives, epoxy-resin-based, 118–119, 120, 125, 127, 129
- aisled frames/structures, 13, 76–77
 - barns, 13, 76, 77, 133
 - hammerbeam roofs and, 72
- alterations, 3, 50–52, 83, 103
- America (USA), 87, 90
- American Lumber Standards Committee (ASTM) D245, 90, 92, 93
- anamnesis, 5
- anatomy
 - medical analogy, 5
 - in survey, 50, 52, 53
- angles, steel, 135, 138
- appearance of structure and following repair, 103, 104
- appointments, 2
- aramid fibre, 118
- arch-braced roofs, 17, 70, 71–72
- architect, appointment, 2
- arris knot, 89
- ashlar pieces, 16
- ASTM D245, 90, 92, 93
- bar(s) (reinforcing/steel), 118, 127, 127–128, 137–138
 - threaded, 111
- bare-faced tenon, 33, 36, 120
- Barlow, P., 21, 87
- barns, 130, 133–135
 - aisled frames, 13, 76, 77, 133
 - box frames, 74
 - purlin
 - case study, 133–135
 - supplementary structures, 130
- basalt fibre, 118
- base cruck, 15, 78–79
- beams
 - end repairs, 121–123
 - joist and beam tenons, 36–38
 - summer (bressummer), 15, 19, 52, 74, 81, 104
 - tie beams, 13, 16, 18, 23, 24, 25, 39, 40–45, 46, 52, 53, 57, 61, 66–67, 70–71, 74, 75, 79, 80, 109, 121, 122, 124
- beetle attack, 26, 55, 56, 59, 65
- Belgian roofs, 18
- bending, members in, 54
 - refacing, 121
 - scarf joint and, 126
 - strengthening, 128–129
- bending stresses, 88, 90–91, 97–98
- bolts, 111
 - forelock, 30, 33, 45
 - stitch, 41, 46, 47
- box frames, 11–13, 74–76
- braces, 13, 15, 16, 17, 18, 35–36, 46, 66, 67, 121, 130
 - arch-braced roofs, 17, 70, 71–72
 - brace tenons, 63, 78, 79
 - braced frames, 35, 36, 43, 76, 78
 - joints and, 43, 44
 - knee, 35, 75
 - structural behaviour and, 71–72, 74–79
- bressummer (summer beam), 15, 19, 52, 74, 81, 104

- brick façades, 50
 - see also* masonry buildings
- brick nogging, 50, 53, 55, 66, 83
- Britain (UK), grading, 87, 95, 98–99
- Brunel, Isambard Kingdom, 87
- BS4978, 94, 95, 97, 98
- BS5268, 86, 90, 91, 94, 95, 97, 110–114, 117
- builder's level, 58
- caged nut, 45
- carbon fibre, 118, 129
- carpenter, reliance on, 106–107
- carpentry, 8, 11, 16, 21, 24, 109
 - structural, 4, 8
- centre lines (of members), 35, 53
- character, historic, 8, 102–103
- clashed purlin roofs, 70, 71
- climate and tree growth rate, 26–27
- code(s), 8, 109–110
 - CP112 (Code of Practice for the Design of Timber Structures), 29, 88–91, 94, 95, 97–98
 - Eurocodes, 8, 98, 110
 - Swedish codes, 80
- cogged joint, 39
- collars, 16–17, 36, 66–67
 - A-frame, 70–71, 139
 - arch-braced, 71–72
 - case studies, 133, 138, 139
 - common rafters, 66–67
 - continental roofs, 18
 - cruck frames, 14–15
 - structural behaviour and, 77–79
- computers (and software), 61
 - cautions, 61–62
- conoid roof, 9
- conservation engineer, 1, 2
 - appointment, 2
 - strength and, 91, 93, 94
- consultants, appointment, 2
- continuous processes, 64
- cotters, 45
- coupled rafter, 67
- CP112, 29, 88–91, 94, 95, 97–98
- creep deflection, 65
 - purlins, 56, 68, 69, 131
- cruck frames, 14–15, 36, 77–78
 - see also* base cruck
- cyclical phenomena, 64
- D245 (US Standard), 90, 92, 93
- damp, 6, 55, 56
- deadlines, 64
- decay and distress
 - causes and types of, 55–57
 - diagnosing/determining, 55–76
 - looking for signs of, 6, 54, 65
 - drills, 59
 - repair *see* repair
- density, 113
 - growth rate affecting, 94, 98
 - joint capacity affected by, 111
- diagnosis (medical analogy), 6
- dismantling decisions, 105–106
- distress *see* decay and distress
- double posts, 46
- dovetail
 - lap dovetail joints, 39, 131
 - wedged half dovetail, 40–41, 77
- draw-bored peg, 34, 36
- drawing board, 58
- drills, decay-detecting, 59
- dry (dried) timber, 28, 29, 88, 95, 96, 116, 117
- drying, 28
 - defects, 28, 56
 - looking for, 54
 - shakes, 93–94
 - shrinkage, 28, 40, 45, 56
 - splits, 54, 93–94
- Dutch roofs, 18
- earthquakes, 62, 64
 - Serbia (Dubrovnik), 102
 - Turkey and Greece, 15
- edge knot, 89, 90
- elasticity (and elastic analysis)
 - aisled frame, 77
 - modulus of elasticity, 87, 96, 118, 129, 139
 - purlin roof, 69
 - reinforcement and, 118
 - strengthening members in bending, 128–129

- epoxy-resin-based adhesives, 118–119, 120, 125, 127, 129
- Eurocodes, 8, 98, 110
- examination (medical analogy), 5–6
- experimental work, 63
- 19th C., 87
- joints, 35, 65
- racking resistance of framing, 44
- face
- knot in, 89, 91
- working, 53
- farm buildings *see* barns
- fasteners (mechanical), 33, 110–118, 122, 124–126
- allowable compression stresses and loads, 40, 149
- groups of, 117–118
- iron, 46
- moisture content and, 116–117
- Fire of London *see* Great Fire of London
- flat lead roofs, 31, 56
- flitch/flitch plates, 127–129
- floors
- double, 19, 21, 51, 82
- insertion into what were once open roofs, 51
- loads, 80–82
- masonry buildings, surveys, 57
- medieval, 15, 17, 81
- post-fire, 18–22
- folding wedges, 43, 45
- force(s)
- horizontal *see* horizontal forces and loads
- with joints, 44
- ironwork, 46, 47
- mortice and tenon joints, 35
- roofs, 66, 70, 71, 74–79
- case studies, 136, 137, 138
- wind, 66, 74, 77
- see also* horizontal forces and loads; loads; vertical forces and loads
- forelock bolts, 30, 33, 45
- frames, 70–80
- A-shape *see* A-frame
- aisled frames *see* aisled frames
- box, 11–13, 74–76
- braced, 35, 36, 43, 76, 78
- continental, 15
- cruck, 14–15, 36, 77–78
- post-fire *see* post-fire structures
- pre-fire, 11–16
- roof, 43, 61, 70–80
- France, roofs, 18
- fungal attack, 6, 26, 55
- gate, case study, 140–143
- Georgianising, 50
- Germany
- frames, 15
- roofs, 18
- supplementary structure, 129
- gibs, 45
- girders, trussed, 21, 136
- grading, 85–99
- historical background, 87
- methods, 88–96
- practical example, 97–98
- grain, slope, 54, 94, 95
- Great Fire of London
- structures after, 18–26
- structures before, 11–18
- see also* medieval structures
- Greece, frames, 15
- green timber, 28, 29, 88, 95, 96, 116, 117
- growth
- hardwood vs softwood tree growth
- characteristics, 26–27
- looking for defects in, 54
- rate
- climate effects, 26–27
- density affected by, 94, 98
- in practical example, 97, 98
- half lap joint, 33, 43
- hall(s), open, insertion of floors into what were once, 51
- hall and cross wing, 11
- hammerbeam roofs, 17, 72–74
- Hampton Court, 30, 46
- hangers, 43
- iron, 20
- Hankinson's formula, 40, 94, 113, 149

- hardwood, 26–27
 - growth characteristics compared with softwood, 26–27
 - harvesting and conversion, 27
 - temperate, grading, 91–93, 95
- haunched and tusked tenon, 37–38
- Hawksmoor's work at Westminster Abbey, 106, 109
- heartwood, 26
 - oak, resistance to beetle attack, 56
- heel joints, 45, 47, 57, 79
 - notched, 41
- heritage buildings (heritage value), 2, 4, 5, 7, 8, 9
 - floor loads, 80
- hinges, Trinity College Gate, 141, 142
- historical analysis, 62, 63
- horizontal forces and loads
 - A-frame roof, 138
 - aisled frames, 76, 77
 - box frame, 74
 - braced frame, 35
 - purlins, 69
 - Trinity College Gate, 142, 143
- Horsham slate, 31, 133
- importance and significance, 3
- infill
 - racking resistance and, 44, 83
 - wattle and daub, 50, 66, 83
- insect (beetle) attack, 26, 55, 56, 59, 65
- Institution of Structural Engineers manual for EC5, 110
- International Council on Monuments and Sites (ICOMOS), 4, 4–5
- International Scientific Committee on the Analysis and Restoration of Structures of Architectural Heritage (ISCARSAH), 4, 102
 - Recommendations*, 4, 62–64
- intervention *see* repairs and interventions
- intervention strategies, 101–107
- Ireland, 18th C. building, 21
- iron (and ironwork), 30, 44–47
 - capacity of ironwork, 47
 - fasteners, 46
 - straps, 30, 40, 44, 45, 79, 140
 - tie rods, 30, 46
- ISCARSAH *see* International Scientific Committee on the Analysis and Restoration of Structures of Architectural Heritage
- Italy
 - ironwork, 44
 - roofs, 23
 - stress grading, 85
- jetties, 11, 15, 75, 104
- joints, 33–48, 65, 123–127
 - behaviour, 65
 - bridle, 33, 41, 42–43, 111, 121, 123–127
 - fastening *see* fasteners
 - green timber and, 29
 - heel *see* heel joints
 - moments on, 43–44, 79
 - notched, 23, 41–42, 115
 - pegged, 33–36, 39, 43–44, 79, 111
 - purpose, 33
 - scarf *see* scarf joints
 - in tension, 35, 40, 43–44, 65
- joist and beam tenons, 36–38
- Jones, Inigo, 23
- king post (trusses), 23, 24, 27, 43–45, 79, 80
- knee braces, 35, 75
- knots, 88–93
 - knot area ratio (KAR) method, 91, 93, 97, 98
 - repairs and, 111
- L-shaped steel, Trinity College Gate, 142, 143
- ladders, 53, 57, 58
- lag (coach) screws, 110, 112, 113, 116, 117
- lap dovetail joints, 39, 131
- lap joint
 - half, 33, 43
 - notched, 15, 38–39
- laser surveys, 49, 59
 - levels, 58
- lateral load on screws, 113
- lead (roofs), 31
 - flat roofs, 31, 56
 - problems, 55, 56

- lead holes (for screws), 113
- level, measuring, 58
- life of a structure, extending life of, 1
- lighting, 58
- limestone slate, 31, 133
- loads, 65–83
 - floor *see* floor
 - horizontal *see* horizontal forces and loads
 - in repairs
 - beam end replacements, 122–128
 - fasteners, 110–118, 149
 - patch at a mortice, 121
 - refacing of a member in bending, 121
 - strengthening members in bending, 129
 - supplementary structures, 130
 - timber replacements, 119
 - roof, 66–80
 - snow 66, 104–105
- vertical *see* vertical forces and loads
see also force
- margin knot, 89, 90, 93
- Marktheidenfeld, building in, 129–130
- masonry buildings, 11, 18, 50
 - floor, 81–82
 - surveys of structures in, 56–57
 - walls, 83
- materials, 26–31
 - supplementary, 109, 129–131
- measurement (general aspects), 6
 - recording, 57
 - see also* surveys
- mechanical fasteners *see* fasteners
- medical analogy, 4–7, 109
- medieval structures, 9, 11, 13
 - cases, 133–138
 - floors, 15, 17, 81
 - joints, 3, 39, 41
 - roofs, 55
- members
 - in bending *see* bending
 - centre lines of, 35, 53
- moisture content, 28–29, 95–97
 - fasteners and, 116–117
 - measurement, 55, 58
 - see also* water
- moments on joints, 43–44, 79
- mortice (and tenon), 33–41, 43–44, 46, 61, 65, 77, 78
 - patch at mortice, 119–120
- muntins, 140–141
- Musschenbroek, Petrus van, 87
- Netherland (Dutch) roofs, 18
- new build, differences from, 7
- Nicholson, MA, 19–21, 23, 87
- Nicholson, Peter, 24, 87
- nogging, brick, 50, 53, 55, 66, 83
- notched beam ends, 36–37
- notched joints, 23, 41–42, 115
- notched lap joints, 15, 38–39
- oak (*Quercus*), 22, 26
 - densities for *Q. rubra*, 111
 - floors, loads, 81
 - grading/strength, 85, 86, 91, 93, 94, 95
 - moisture content, 28
 - resistance of heartwood to beetle attack, 56
- open halls, insertion of floors into what were once, 51
- open roofs, enclosing of, 51
- original design, inadequate, 103, 131
- outward thrust, 15, 16, 17, 39, 40, 46, 47, 66–71, 74, 76, 77, 79, 130, 137, 138, 139, 140
- Oxford Road Station (Manchester), 9, 103
- partitions, 22, 83
- patch at mortice, 119–120
- pegs (pegged joints), 33–36, 39, 43–44, 79, 111
- photographs, 53, 58
- plates (steel), 127–129
 - flitch plates, 127–129
 - shear plate connectors, 107, 110, 116
 - wall plates *see* wall plates
- plumb line, 58
- Poland, frames, 15
- portcullis structure, 43, 140, 141
- post-fire structures, 18–26
 - softwood, 27–28
- pre-fire structures, 11–18
 - see also* medieval structures

- Price, Francis (1733), 23, 24, 79, 81, 82
- process, 2–4
- pugging boards, 22
- purlins, 15, 16, 17, 18, 24, 66, 68–70, 71, 130–131
 - barns *see* barns
 - case studies, 133–135, 138, 140
 - clasped, 70, 71
 - creep deflection, 56, 68, 69, 131
 - loads, 68–70, 71
 - ridge, 15, 18, 77
- purpose, 1–2
- qualitative analysis, 62–63
- quantitative analysis, 62
- queen post (trusses), 22, 25, 44, 46, 70, 80, 109
- Quercus see* oak
- racking (and racking resistance/prevention)
 - on frames, 44, 83
 - on roofs, 67, 106
 - rafter roofs, 16
- rafters, 16
 - continental, 18
 - thrust *see* thrust
- Rebuilding Act (post-fire), 22
- refacing of member in bending, 121
- repairs and interventions, 101–132
 - earlier/previous, 106, 131
 - strategies, 101–107
 - timber for, 29, 109, 119
- report (survey), 54–55, 101–102
- ridge purlin, 15, 18, 77
- ring shake, 94
- roofs, 16–18, 23–26, 30–31, 66–80, 133–140
 - arch-braced, 17, 70, 71–72
 - case studies, 133–140
 - common, 66–67
 - conoid, 9
 - continental, 18
 - frames, 43, 61, 70–80
 - loads on, 66–80
 - materials, 30–31
 - open, enclosing of, 51
 - post-fire, 23–26
 - pre-fire, 16–18
 - purlin *see* purlins
 - racking on *see* racking
 - supports *see* supports
 - surveys (for distress)
 - early buildings, 55
 - masonry buildings, 56–57
 - tie beams *see* tie beams
 - trusses *see* trusses
 - types, 16–18
- rupture, modulus of, 87, 88, 94, 96, 129
- S1–S3 (strength grades), 90–91
- St Mary-at-Hill, 4, 64, 105, 135–138
- scantlings, 54
 - early buildings, 55
 - masonry building and tables of, 81–82
- scarf joints, 33, 42–43, 111, 114, 121, 123–127
 - half, 124
 - tabled, 43, 126, 127
- scissor braces, 16
- screws, 112–115
 - coach/lag, 110, 112, 113, 116, 117
 - self-tapping, 112, 114–115
- self-tapping screws, 112, 114–115
- shakes, 93–94
- shear plate connectors, 107, 110, 116
- shear stress, 36, 37, 42, 77
 - repairs and, 115, 128
- short grain timber, 35, 42
- shrinkage, 28, 40, 45, 56
- significance and importance, 3
- single floors, 1
- slate, 31
 - gritstone, 32
 - Horsham, 31, 133
 - limestone, 31, 133
 - Welsh, 18, 30, 31, 51, 66, 133
- software *see* computers
- softwood, 27–28
 - grading, 85, 86, 87, 91, 94, 95, 97, 98
 - growth characteristics compared with hardwood, 26–27
- specialist surveys (incl. equipment), 49, 54, 58–59

- species of trees
 - identifying, 54
 - strength grades (S1–S3), 90–91
- splay knot, 89, 91
- split(s), 54, 93–94
- split-ring connectors, 110, 116, 124
- square abutments, 43
- square pegs, 33, 39
- steel (for repair), 109, 118, 121, 128–129
 - case studies, 134, 135, 137, 138, 142, 143
- stepped notched joint, 41
- stiffness
 - joints, 61, 62
 - moisture content and, 95
- stitch bolts, 41, 46, 47
- stop splayed scarf, 43
- straps (iron/metal), 30, 40, 44, 45, 79, 140
- strategies for interventions, 101–107
- straw thatch, 30
- strength, 28, 85–99
 - of members in bending, increasing, 128–129
- stress(es)
 - bending, 88, 90–91, 97–98
 - compression, allowable, in Hankinson's formula, 40, 149
 - grading of, 85, 87
 - working, allowable/acceptable, 94–95
- structural analysis, 53, 63, 64
- structural carpentry, 4, 8
- structural engineer, appointment, 2
- Structural Use of Timber, The (BSI, 1972), 88
- structure(s)
 - behaviour, 61–84
 - extending life of, 1
 - in masonry buildings, 56–57
 - measurement *see* measurement
 - new, differences from, 7
 - pre-fire (of London), 11, 11–18
 - see also* medieval structures
 - survey *see* survey
- strutted principals, roof frame with, 61
- stud tenons, 104, 120
- summer beam (bressummer), 15, 19, 52, 74, 81, 104
- supplementary structures, 109, 129–131
 - purlins, 130–131, 133–135
 - Trinity College Gate, 143
- supports (roof)
 - box frame and, 75–77
 - cruck frames and, 77
- survey, 5, 6, 9, 49–59
 - desk, 5, 51–52
 - detailed *see* detailed survey
 - equipment, 57–58
 - preliminary, 50–53
 - the report, 54–55, 101–102
 - scope of, 5, 52–53
 - specialist, 49, 54, 58–59
- surveys, 9
- Swedish building codes, 80
- T section, 129
- tabled scarf joint, 43, 126, 127
- temperate hardwood, grading, 91–93, 95
- tenon(s)
 - bare-faced, 33, 36, 120
 - brace, 63, 78, 79
 - joist and beam, 36–38
 - mortice and *see* mortice
 - replacement timber and, 123–124
 - stud, 104, 120
- tension
 - across grain, self-tapping screws and, 115
 - joints in, 35, 40, 43–44, 65
 - screws in, 114
- Tewkesbury Abbey, 40
- TH1 and TH2 grades, 85–86, 95
- THA and THB grades, 85–86, 91, 95
- thatch, 30
- threaded bars, 111
- thrust (roofs/rafters), 16, 66, 70, 71, 73, 74, 77
 - case studies, 137, 139, 140
 - ironwork and, 46
 - outward, 15, 16, 17, 39, 40, 46, 47, 66, 67, 69, 70, 71, 74, 76, 77, 79, 130, 137, 138, 139, 140
 - purlins and, 69
- tie beams, 13, 16, 18, 23, 24, 25, 39–46, 52, 53, 57, 61, 66–67, 70–71, 74, 75, 79, 80, 109, 121, 122, 124

- tie rods, iron, 30, 46
- tiles, 30
- timber, 26–29
 - choice, 26
 - dry/dried timber, 28, 29, 88, 95, 96, 116, 117
 - green, 28, 29, 88, 95, 96, 116, 117
 - repair with, 29, 109, 119
 - see also* trees
- Timber Design and Construction Handbook*, 96
- Timber Designers' Manual*, 80, 96
- time factors, 64
- treatment (medical analogy), 7, 109
- Tredgold, Thomas, 3, 81, 87
- trees
 - growth rate, 26–27
 - species of *see* species
 - see also* hardwood; softwood; timber
- Trinity College Gate (Cambridge), 140–143
- trusses (trussed roofs), 23–26, 79–80
 - king post, 23, 24, 27, 43, 44, 45, 79, 80
 - queen post, 22, 25, 44, 46, 70, 80, 109
 - trussed girders, 21, 136
 - trussed partitions, 22
- Tudor building, 52
- Turkey, frames, 15
- tusked tenon, 19
 - haunched and, 37–38
- twist strap, 46

- UK (Britain), grading, 87, 95, 98–99
- undersquinted abutments, 43
- United Kingdom (UK; Britain)
 - Code of Practice for the Design of Timber Structures (CP112), 29, 88–91, 94, 95, 97–98
 - grading, 87, 95, 98–99

- United States of America (USA)
 - grading, 87, 90
 - Wood Handbook*, 90, 95, 113
- unpredictable events, 64
- US *see* United States

- V joint, 125
- van Musschenbroek, Petrus, 87
- vertical forces and loads, 16, 65–66
 - purlins, 68

- wall(s), 55–56, 83
 - loads, 83
 - post-fire, 18–22
 - surveys (for distress), 55–56
- wall plates, 6, 11, 16, 33, 39–42, 52, 55, 66–70, 73, 74, 77–79, 122, 124
 - barns, 130
 - case studies, 133, 138, 139, 140
- wall studs, 55, 66, 74, 81, 85, 104, 130
- washers, 112–115, 126
- water
 - harvested timber, 28
 - penetration in roofs, 55
 - see also* moisture content
- wattle and daub fill, 50, 66, 83
- Weald and Downland Museum, 120, 125
- Wealden house, 11
- wedge(s), folding, 43, 45
- wedged half dovetail, 40–41, 77
- Welsh slates, 18, 30, 31, 51, 66, 133
- Westminster Abbey, 106, 109
- Westminster Hall roof, 64, 72
- wind braces, 17, 130
- wind forces, 66, 74, 77
- Wood Charter (ICOMOS, 2017), 4
- Wood Handbook*, 90, 95, 113
- working face, 53
- Wren, Christopher, 16, 23, 25, 30, 135, 136