Lawrence, Andrew and Ross, Peter

ISBN 978-0-7277-6178-1

<https://doi.org/10.1680/arts.61781.267>

ICE Publishing: All rights reserved

Index

Page numbers in *italics* refer to illustrations and tables.

- accelerometers 62
- accidental damage 62–64, 66, 88
- acoustic grading 79
- adhesives 23–24, 61, 116–119, 252
- Alderham Farmhouse case study 238–245
- All Saints Church, London *18*
- alterations
 - cultural significance 122–123
 - listed buildings 123–124
 - proposed 66
 - strength reducing 63
- analysis model, strength 83–84
- appraisals 69, 82–89
- arch action 7, 8
- Arkwright's Mill building, Derbyshire *81*
- audits, cultural significance 121–123
- auger drilling 76–77, *179*
- Avoncroft cruck barn 5

- balloon frames 20
- Banqueting House, London 11
- barns *xii*, 5
- Beaulieu Church, Hampshire case study 181–187
- beetle attack 50, 181–182, 190
- Belfast truss 15, 206–212
- Bell Inn, Gloucester case study 195–198
- Bessie Surtee's House, The Quayside, Newcastle-upon-Tyne *71*
- boltlams 15, 17, 129
- boxed heart 143
- bracing 59, *216*
- bricks 7, 10–11, 22
- Bridge House, Kent case study 246–249
- Brighton Dome Corn Exchange case history 199–205
- brown rots 49
- BS 5268 93–95, 251–252, 259–262
- building legislation 91–97 *see also* codes

- case studies
 - Alderham Farmhouse 238–245
 - Beaulieu Church, Hampshire 181–187
 - Bell Inn, Gloucester 195–198
 - Bridge House, Kent 246–249
 - Brighton Dome Corn Exchange 199–205
 - 26–28 Charlotte Square, Edinburgh 155–161
 - Cranbrook Church, Kent 168–177
 - Duxford airfield hangars 206–212
 - Kings Cross Station 178–179
 - Manchester Art Gallery 162–166
 - Royal Festival Hall 150–154
 - St Mary the Virgin, Sandwich 188–194
 - Tyne Theatre 230–236
- cast iron 14
- cathedrals *see* churches and cathedrals
- Centre Pompidou-Metz *180*
- change of use 66, 91
- characteristics of timber
 - behaviour in fire 46
 - commercial supply 44–46
 - durability 35, 53–56, 54, 55
 - grades 43–44
 - moisture content and movement 33–36
 - strength 36–37
- 26–28 Charlotte Square, Edinburgh case study 155–161, 253
- charring
 - damage 63, 88
 - rate 46, 128
 - Tyne Theatre 231
- Chatham Dockyard 15, *16*, *17*, 98
- cill plates *106*, 107
- classification of trees 31–32
- client brief 66
- CLT (cross-laminated timber) 19, 26, 28, 44, 45
- coatings, protective 57
- codes 251–252, 261–262
- commercial supply of timber 44–46
- commission 66–67, 76–79
- common building timbers 35
- computer fabrication 25–26

- concealed areas of structure 74
- conditions of engagement 67
- contracts 136–138
- corrosion of fasteners 60
- CP112 43–44, 93, 105, 251
- Cranbrook Church, Kent case study 168–177
- creep deflection 85–86, 96–97, 210, 212
- Cromford Mills, Derbyshire 81
- cross-laminated timber *see* CLT
- crown-post roofs 7, 8
- cruck frames 5, 7, 8
- cultural significance audits 121–123, 157–158
- Cutty Sark, Greenwich 135

- damage, accidental 62–64, 65, 88
- Darby, Abraham 14
- dating timbers 79–80
- datum points 85
- decay
 - causes of 48–50
 - checking for 76–79
 - prevention of 53–57
 - risk of 50–53
 - treatment of 57
- defects
 - patent 66
 - range of 59–60
 - strength reducing 39–40, 42
- deflection
 - creep deflection 85–86, 210, 212
 - limits 85–86, 96–97
- deformation 61, 85–86
- de-frassing 193
- delamination 119
- dendrochronology 79–80
- density of timber 39, 41–42
- design procedures for BS 5268 252
- deterioration of joints 60–61
- diagnostic sequence 69–70
- diaphragm action 22, 59
- dismantling and re-erection 146, 239–245
- distortion, drying 34–36, 42, 101–106
- documentation, contract 137
- dry rots 49–50, 168–170
- durability
 - appraisal 87–88
 - by design 53–56, 149
 - classes 55
 - natural 35, 53
 - timber specification 141
- duration of load 39, 41, 94, 96, 255, 256–257, 256
- Duxford airfield hangars case study 206–212

- earlywood cells 32
- eighteenth century building form 10–13
- elastic modulus 33, 191–192, 257
- Eltham Palace, London 47
- Ely Cathedral, Cambridgeshire 2
- EMC *see* equilibrium moisture content
- engineered timber 18, 23, 44
- environmental conditions and timber performance
 - 50–53
- epoxy resins 117–118
- equilibrium moisture content (EMC) 33, 51, 87
- erection of trusses 214, 234, 235
- Eurocode 5 93–97, 259–260
- European spruce 28
- explosion damage 63
- extensions *see* alterations

- fastener corrosion 60
- fees 67, 131
- fibre saturation point (FSP) 33
- fire
 - behaviour of timber in fire 46
 - damage 63–64, 89
 - additional fire resistance 127, 128
 - Tyne Theatre 231, 233–234
 - York Minster 214–215, 216, 217, 221
- fissures 7, 35, 37, 41, 42, 124
- flitch plates 113–115, 114
- floors
 - building regulations 92
 - 26–28 Charlotte Square, Edinburgh 155–161, 156, 157
 - nineteenth century 14, 17, 19
 - seventeenth and eighteenth centuries 11, 12
 - strengthening 125–126, 125, 195–198
 - vibration 62
- formaldehyde adhesives 23–24, 61, 116–117, 119
- foundations 106, 107
- frames
 - infill 6–7, 245
 - medieval 5, 7, 8
 - moving 145–148, 239–245
 - nineteenth century 15, 19
 - remedial work 101–113
 - twentieth century lightweight *see* platform frames
- FSP (fibre saturation point) 33
- fungal attack *see* rot

- German Gymnasium, Kings Cross 129
- Gloucester Docks warehouse 14
- glued joints deterioration 61
- glues *see* adhesives
- glulam (glue laminated timber) *see* engineered timber

- grading
 26–28 Charlotte Square, Edinburgh 155–161
 codes and standards 251–252
 Cranbrook Church, Kent 171–172
 Manchester Art Gallery 164
 rules 43–44, 79, 164, 251
 graveyard test 53
 Great Coxwell Barn, Oxfordshire *xii*
 green oak 101–107, 218
 greenheart 37, 38
 growth rate 41–42
 growth rings 30, 31, 80
 The Guildhall, Lavenham, Suffolk 6, 68
- Halle au Blés, Paris 199
 halls, medieval 5
 hammer probes 78
 hammerbeam roofs 7, 8, 47
 Hampton Court 10
 hardwoods
 characteristics 31, 32, 35
 supply 45–46
 temperate hardwoods 142–143
 tropical hardwoods 45
 heartwood 30, 31, 32
 highland style timber frames 6
 historic buildings
 cultural significance 121–123, 241
 remedial work 123–124
 upgrading 124–128
 history of timber construction
 medieval period 4–10
 nineteenth century 13–18
 seventeenth and eighteenth centuries 10–13
 twentieth century 18–28
 HMS Unicorn, Dundee 90, 122
 Holy Trinity Church, Blythburgh, Suffolk 65
 100-year rule 82–84, 105
- ICOMOS (International Council on Monuments and Sites) 121
 in situ strength grading 79
 Industrial Revolution 13, 15
 insect attack 50, 181–182, 190
 inspections, visual 72–74
 insulation 20, 126–128, 126, 243
 insurance 88–89
 International Council on Monuments and Sites (ICOMOS) 121
 iron straps 10, 11
- jacking (and propping) 106, 107, 212
 jetties 5–7, 8, 58, 68, 71
- joints
 compression 108–110, 110, 113
 deterioration 60–61
 mortice and tenon 7, 9, 101
 notched lap 7, 9
 post head and tie beam 9, 10, 109
 scarf *see* scarf joints
 shear 110, 111, 113
 tension 110, 111, 113
- KAR (knot area ratio) system 43
 Kenton Church, Devon 5
 king-post trusses 11, 12, 13
 Kings Cross Station case study 178–179
 knot area ratio *see* KAR
 knots 37, 40, 42, 43, 79, 140, 141, 163, 164, 172, 175
- laminated veneer lumber (LVL) 24
 later additions *see* alterations
 latewood cells 32
 legislation, building 91–97 *see also* codes
 lift-and-slide method 146–148, 147, 148, 246–249
 lightweight timber frame *see* platform frame
 litigation reports 66–67
 Littledown Sports Centre, Bournemouth 144
 load duration *see* duration of load
 load sharing 254
 load shedding 86
 load testing
 26–28 Charlotte Square, Edinburgh 155–161, 158, 160
 procedures 253–257
 Royal Festival Hall 152–154
 strength appraisal 84
 load-bearing partitions 12, 13
 load/deflection relationship 256–258, 256
 lowland style timber frames 6
 LVL (laminated veneer lumber) 24
- Madison curve 41, 255
 Manchester Art Gallery case study 162–166
 Mathematical Bridge, Queens' College, Cambridge 75
 MC *see* moisture content
 medieval building form 4–10
 metal fasteners 60, 111–112, 112
 metal reinforcement 113–115, 114
 Metropal Parasol, Seville 213
 micro-drilling 77
 mills 14, 17, 81
 model forms of repair 99–101, 100, 178
 Modernism 20
 modifications to historic buildings *see* alterations
 modulus of elasticity 33, 191–192, 257
 modulus of rupture 37, 257

- moisture content
 - adhesives 116–117
 - creep deflection 85–86
 - effect on strength 36–44
 - measurement of 77–79
 - movement due to 32–36
 - specification 141–142
- monitoring movement 84–86, 181, 205
- mortice and tenon joints 7, 9, 101
- Mossbourne Academy, London 149
- movement, moisture 32–36, 45, 85, 101–104
- moving timber frames 145–148, 239–245
- nails 15, 20
- National Structural Timber Specification* 137
- natural durability 53
- Newcastle Catholic Cathedral 120
- nineteenth century building form 13–18
- noise transmission 61–62
- notation, codes of practice 252
- notched lap joints 7, 9
- oak frames 104–105, 107
- Octagon at Ely Cathedral, Cambridgeshire 2
- oriented strand board (OSB) 20, 22
- overload damage 61–63, 191
- patent defects 66
- Paycocke's House, Essex 6
- Penshurst Place, Kent 29
- permissible stresses 43, 84, 93–95, 252
- phasing survey work 70
- photographs 73–74, 132
- photosynthesis 30
- platform frame 20–23, 60
- plywood 22, 24
- population sampling 255
- portals 7, 8, 101
- posthead and tie beam joints 9, 10, 109
- precontract work 136
- preservative treatments 56, 87
- propping and jacking 106, 107, 212
- protective coatings 57
- Protimeter 78–79
- pugging 11, 13
- queen-post trusses 11, 12, 13
- radial shrinkage 34
- radiocarbon dating 80
- recording techniques 73
- redwood 37, 38
- regulations, building 91–97 *see also* codes
- reinforcement 113–115, 114, 115, 181–187, 195–198
- relative humidity 33–35, 33, 50
- Renaissance 11
- render infill 245
- repairs
 - adhesives 116–119
 - beam ends 99–101, 100, 113–115, 170–174
 - contracts 70, 136–138
 - floors 124–126, 195–198
 - historic buildings 123–128, 168–179
 - member replacement 214–236
 - metal reinforcement 113–115, 114, 181–194, 199–204, 204, 205
 - truss ends 178–179
 - model forms 99–101, 100
- replacement of members 107–113, 193, 242
- reports 130–133
- residual risks 87–88
- retardants, fire 142
- reversible remedial work 124
- RH (relative humidity) 33–35, 50
- roof trusses
 - Duxford airfield hangars 206
 - York Minster 219–220
- roofs
 - Brighton Dome Corn Exchange 199–205
 - Cranbrook Church, Kent 168–177
 - hammerbeam 7, 8, 47
 - Manchester Art Gallery 162–166
 - medieval 4, 7
 - nineteenth century 15, 19
 - Penshurst Place, Kent 29
 - Savill gridshell roof 167
 - seventeenth century 11
 - St Mary the Virgin, Sandwich 188–194
 - twentieth century 20
 - York Minster 216, 219
- rots 48–52, 55, 87, 168–170, 178–179
- Royal Festival Hall case study 150–154
- rupture, modulus of 37, 257
- safety issues
 - accidental damage 63–64, 88–89
 - load testing 255
- St Andrew, Greensted-juxta-Ongar, Essex x
- St Mary the Virgin, Oxford 122, 123
- St Mary the Virgin, Sandwich case study 188–194
- St Mary's Catholic Cathedral, Newcastle 120
- salt water exposure 53
- sapwood 30, 31, 32, 53, 56, 143
- Savill gridshell roof 167
- scarf joints 9, 10, 99, 107–108, 109, 110, 111, 112, 171, 173, 176, 244

- scarf repairs 107–108, 111–112, 170–176
- scissor bracing 214, 215
- scissor scarfs 108, 110
- self-tapping screws 24, 25, 118
- Serpentine Pavilion 26
- Serpula lacrymans* (dry rots) 49–50, 168–170
- service classes 82
- service life 82
- seventeenth century building form 10–13
- The Shambles, York 58
- shear joints 110, 111, 113
- shear strength 38
- ships 90, 122, 135
- shrinkage 33–36, 34, 101–103, 105
- SIPs (structural insulated panels) 20
- site boundaries 137
- Sky Believe in Better Building, West London 27, 237
- slip tenons 106, 107
- slope of grain 41, 42, 111, 163, 200
- smoke damage 64
- Snape Maltings Concert Hall, Suffolk 139
- snow loading 96, 164–166
- softwoods
- characteristics 31, 32, 35
 - specification 140–141
 - supply 44–45
- sound transmission 61
- species 28–35, 44–45, 140, 142
- specification of repairs 137, 140–143
- Speke Hall, Liverpool 6
- splice plates 112, 113, 114, 117, 125, 178, 186, 187, 204, 205, 231
- splits 35, 41, 63
- stability 59, 83–85, 101
- Stadthaus, London 27
- steel
- epoxy-bonded 118–119
 - ties 115–116, 115, 192, 193
- stiffness (modulus of elasticity) 33, 191–192, 257
- strength
- appraisal 82–84
 - characteristics 36–37
 - classes 251, 252
 - duration of load relationship 255, 256
 - grading 79
 - 100-year rule 83
 - moisture content 36–44
 - reducing defects 39–40
 - timber specification 141, 143
- strengthening floors 125–126, 155–161, 195–198
- structural insulated panels (SIPs) 20
- superimposed loads 95–96, 155–161
- surface treatment 57, 141–142
- surveys
- commissioning 76–80
 - moving timber frames 145, 239, 241
 - phasing 69–70
- tangential shrinkage 34
- temperate hardwoods 45–46, 142–143
- Temple Meads, Bristol 15, 16
- temporary works
- in contract specifications 138
 - temporary roofs 89, 138, 221, 222, 223
- tendering for repairs 136–137
- tension joints 110, 111, 113
- thermosetting adhesives 117
- tie rods 115, 181, 182, 183, 192–193, 201, 202, 231, 232
- Timber Frame 2000 project 22
- treatability 35
- treatments
- preservative 56
 - surface 141–142
- Tredgold, T. 18
- triangulation 5, 7, 59, 101
- tropical hardwood supply 45
- trussed rafters 20, 22, 59, 60, 93
- trusses 11, 13, 15, 21,
- twentieth century building form 18–28, 155–161
- Tyne Theatre case study 230–236
- UK timber design codes and standards 251–252
- Unicorn (frigate) Dundee 90, 122
- upgrading historic structures 124–128
- use classes 50–53
- vaults 181–187, 218, 224, 226
- ventilation, lack of 51
- vibration of floors 62
- visual inspection 72–74
- wane 40, 143
- warehouses 14, 17
- water damage from fire fighting 64
- wattle and daub 7
- wet rots 49, 55, 178–179
- white rots 49
- wind loading 96
- wood-boring insect attack 50, 181–182, 190
- York Minster case study 214–229